

Trickle Vent Installation Guide

1. Internal Trickle Vent – Square shaped with foam insert
External Trickle Vent – Triangular shaped with grill insert
2. Align Internal Trickle Vent centrally to pre-routed slot on Top Track with foam section facing the Aluminium
3. Mark and pre-drill fixing holes to suit hole on vent
4. Fix using self tapping screws
5. Mastic/seal if required
6. Apply same process for external Trickle Vent
7. When securing external Trickle Vent ensure that the grill is facing down